

**ECpvX Master Controller**  
*ECpvx S, M, L or Solar*  
Connected on LAN with ECpvX  
Cluster and Slave units

**ECpvX Cluster Controller**  
Connected on LAN with ECpvX  
master and Slave units

**ECpvX Slave controllers**  
*ECpvX Solar*  
Modbus RTU or TCP to the BESS  
Up to 32 BESS under a single Cluster  
Controller

