ENcombi



ECpvh Datasheet



Overview

Is the **EN**combi plug and play controller for decentralized PV plants with hybrid inverters with or without gensets. Pick any interface protocol from our list of supported interfaces and connect - it is that easy!

Connect with inverters, controllers and power meters via RS-485 or TCP/IP and have full control of your grid export / self-consumption and safely run your gensets while saving fuel in hybrid plants

Setup and monitoring is easily done via the built-in webserver, **EC**web, describing every step of the setup and providing you with a wide range of monitoring and reports - run it on your PC or on mobile devices. With the **EC**logic feature, you can program custom logics - a simple and powerful tool.

Use the **EC**cloud remote monitoring system web app for live and historical data visualization and analysis of your PV and PV-Genset plants. You can try it out for a full 90 days free of charge when purchasing any **EC**pvh variant.



Variants

The **EC**pvh comes in the following five variants all running on the same HW.

Capacity

Function \ Variant	Logger	Solar	S	М	L
16 inverters	•	•			
16 gensets	•	•	•	•	
16 grid connections	•	•			
16 PV feed in points	•	•			
Stacking support for >16 inverter PV plants		•			

Control

Function \ Variant	Logger	Solar	S	М	L
EClogic	•	•	•		
Active power control of PV plant		•	•	•	•
Reactive power control of PV plant		•			•
Self consumption unlimited PV plant capacity		*	*	*	*
PV/Diesel up to 100kWp PV plant			•	•	
PV/Diesel up to 500kWp PV plant					•
PV/Diesel unlimited PV plant capacity					*
Genset Management			•		

^{*} Limited by the maximum amount of inverters supported only



Monitoring

Function \ Variant	Logger	Solar	S	М	L
ECweb	•	•	•		
ECpanel	*	*	*	*	*
ECcloud - 90 days free trial	•	•	•	•	
ECcloud	*	*	*	*	*

^{*} Accessories

Communication

Function \ Variant	Logger	Solar	S	М	L
Hybrid inverters via Modbus RTU or TCP			•		
Power meters via Modbus RTU or TCP	•	•	•	•	
Genset controllers via Modbus RTU or TCP	•	•			
Sensors via Modbus RTU	•	•	•	•	
Modbus TCP server	•	•	•	•	•
Modbus RTU slave	*	*	*	*	*

^{*} On RS485 serial port not used for inverter, power meter, genset controller or sensor comm.



Logs and notifications

Function \ Variant	Logger	Solar	S	М	L
Lifetime event log on USB or SD-card	•	•	•	•	
Summary logs on USB or SD-card	•	•			
Production (time series data) logs on USB or SD-card	•	•	•	•	•
Alarm notification via email	•	•	•	•	•
Logs via email or ftp	•	•	•	•	•

HW Specifications

The hardware is a high quality, fast and extremely compact and DIN rail mounted unit allowing you to fit it into almost any electrical cabinet at your site when doing brown field projects - or as a part of our **EC**cube offering.

Ethernet	1 x RJ45 - 10/100Mbs
RS485	2 x isolated fieldbus (master/slave)
Memory	8GB Industrial grade SD card included
Power supply	24Vdc ±15% / 250mA max
Operating Temperature	-20°C to +70°C
Mounting	DIN rail
Dimension	107 x 22.5 x 119 mm (H x W x D)
Weight	About 200g

For more information visit:

www.encombi.com